

Technical Service Bulletin

To: Allied Service & Help Desk Personnel

From: Allied Electronics, Inc.

Date: May 22, 2023

Re: Enabling TCP/IP Communications to the Tank Gauge

Introduction:

The purpose of this document is to explain the process of enabling TCP/IP communications between the tank gauge and the Allied forecourt controller via the ANDI_DGS utility.

There is a presumption that the individual(s) performing the following procedure have acquired a basic understanding of the Allied forecourt controller and the ANDI_DGS utility.

This includes being able to set up and log on as an "administrator" (Refer to the TSB, "ANDI_DGS Username and Password Management.pdf" for more information). This also includes being able to modify port assignments. (Refer to the TSB, "ANDI_DGS Port and IO Board Assignment Function.pdf" for more information).

Required:

- ✓ ANDI_DGS utility
- ✓ Knowledge of the tank gauge's IP configuration and scheme
- ✓ Knowledge of the tank gauge's TCP port

Contact Allied Electronics technical support for the required files and ANDI_DGS utility.

Procedure:

- 1. Launch DGS and connect to the forecourt controller via Ethernet. Note: This procedure will **NOT** work if connected to the forecourt controller using a serial connection.
- 2. Verify that the user is logged on as an "administrator."
- 3. Click on the Utilities tab and then CF Access. A Compact Flash Configuration form will appear.

Superior Technology Now and Into the Future!

P.O. Box 624 • 1414 Radcliffe Street Suite 120 • Bristol, PA 19007 • 215.785.6200 • FAX 215.785.0230 www.AlliedElectronics.com • Sales@AlliedElectronics.com 4. Under "Port and Board Assignment," select COM2 and set it to "Not in Use" followed by clicking "Change Port" and "Apply Changes."

ard Assig	gnment			
I/O Board				
Port 2	~	Port Functi Not in Use	ons ~	
ort	Restore	Defaults	View All	
Apply		hanges	?	
	ort 2	ort Apply C	ard Assignment I/O Board Port 2 Port 2 Port Functi Not in Use ort Restore Defaults Apply Changes	ard Assignment I/O Board Port 2 Port 2 Port Functions Not in Use ort Restore Defaults View All Apply Changes ?

- 5. While still on the Compact Flash Configuration form, look for the section "Extended Configuration Items."
- 6. Click the Section> button until you navigate to the [TCP_LOGGING] Section. Click the Item> button until you get to FIM. Use the dropdown menu to select "True."

Extended Configuration Iter	ns		
< Section < Item	[TCP_LOGGING] FIM True	~ Apply	Item > Section >
Specify the level of TCP/IP interfa	ce message logging		.::

- 7. Click the "Apply" button.
- 8. Click the Section> button until you navigate to [TANK_GAUGE]. Enter the IP address of the tank gauge and click the "Apply" button:

Extended Configuration Iten	IS		
< Section < Item	[TANK_GAUGE] IpAddress 10.0.3.123	Apply	Item > Section >
Tank Gauge Setting			.::

Superior Technology Now and Into the Future!

P.O. Box 624 • 1414 Radcliffe Street Suite 120 • Bristol, PA 19007 • 215.785.6200 • FAX 215.785.0230 www.AlliedElectronics.com • Sales@AlliedElectronics.com 9. Click the Item> button until you get to TcpPort. Enter the TCP Port as configured on the tank gauge and click the "Apply" button.

Extended Configuration Iten	IS	
< Section < Item	[TANK_GAUGE] TcpPort 35555 Apply	Item > Section >
Tank Gauge Setting		.::

10. Back at the Utilities tab, click the "Reset" button and select Warm Start->Immediately->OK:

1	Reset	×
	Reset Type	
-	Warm Start	
	○ Cold Start	
	O Reset Dispensers	
	O Restart Application	
st	○ Boot Diagnostic	
o S	Reset Mode	
,	After	
R	2023 Apr 06 15:06	
2 f	OK Cancel	

11. The forecourt controller will warm start. Upon reboot and connection with the point-of-sale, connect with DGS and navigate to the Status tab. You should observe that port 2 is set to NON:

F	ort Status				
	Port	Function	State	Status	^
	1	POS	Disconnected	CTS & DSR Not Active	
	2	NON	Not Used	Port Not In Use	
	3	CRW	Disconnected	Timeout (No ACK/NAK) Error	

Superior Technology Now and Into the Future!

P.O. Box 624 • 1414 Radcliffe Street Suite 120 • Bristol, PA 19007 • 215.785.6200 • FAX 215.785.0230 www.AlliedElectronics.com • Sales@AlliedElectronics.com You should also observe that one of the virtual ports (17 thru 32) is now assigned as TLS with an Active state:

23	100	Disconnected	External Device Log OII
24	POS	Disconnected	External Device Log Off
25	TLS	Active	Link OK
26	NON	Not Used	Port Not In Use

Note: The status will only transition to "Link OK" when there is data to send or receive. Otherwise, it is normal for the status to be "External Device Log Off."

Contact Allied Electronics Technical Support with any questions or concerns:

800-223-3619 SupportRequest@AlliedElectronics.com